



Russell Hobbs

INSTRUCTIONS and WARRANTY



FOR THE FOLLOWING MODELS:

RHDEBCF – Double fitted fleecy electric blanket

RHQEBCF – Queen fitted fleecy electric blanket

RHKEBCF – King fitted fleecy electric blanket

Extend your 1 year retail warranty to an additional
1 year by registering your purchase here:



Thank you for purchasing the Russell Hobbs Electric Blanket. Each unit is manufactured to ensure safety and reliability.

IMPORTANT SAFEGUARDS

Read this instruction leaflet carefully as it has important information both for operational use and your safety. Save these instructions.

- Use this electric blanket as an under-blanket only.
- Ensure that you know how your electric blanket functions and how to operate it.
- Maintain the electric blanket in accordance with the instructions to ensure that it functions properly.
- Keep this manual with the electric blanket. If the electric blanket is to be used by a third party, this instruction manual must be supplied with it.
- The safety instructions do not by themselves eliminate any danger completely and proper accident prevention measures must always be used.

No liability will be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling.

When using electrical goods always observe the safety regulations to reduce the risk of failure, fire, personal injury and electric shock. Always ensure you check the power supply corresponds to the voltage on the rating label.

- When storing the blanket, allow it to cool down before folding.
- This electric blanket is not to be used by children under 3 years.
- The appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure they can use the appliance safely.
- Check to ensure that the controller(s) and supply cord(s) cannot become trapped in any bed or bedding. Keep the controller(s) outside the bedding as much as possible.
- Avoid extended use of your electric blanket at a high setting. This may result in skin burns.
- Inspect your blanket regularly for signs of wear or damage. If there are signs of or if the blanket has been misused, return it to the supplier prior to any further use.
- This electric blanket is designed for domestic use only. It

is not intended for use in hospitals.

- This electric blanket is not to be used by people who are helpless, by infants, or by people who are insensitive to heat.

WARNING:

1. Do NOT use on or under a waterbed.
2. Do NOT use on an adjustable bed such as a bunk or sofa bed.
3. Do NOT switch on if moist or wet.
4. Do NOT allow the heating wires to lie over the edge of your mattress.
5. Do NOT insert safety pins, needles or other sharp items into the blanket.
6. Do NOT use the electric blanket folded or rucked and avoid creasing.
7. Do NOT use a Double blanket on a single bed.
8. Do NOT tuck the blanket in.
9. Do NOT leave the electric blanket on indefinitely.
10. Do NOT use plastic, rubber backed, heavy or dense overlays as they may lead to overheating.
11. Do NOT crease the blanket by placing items on top of it during storage.

This electric blanket is designed for domestic use only.

Instructions are for the following Electric Blankets:

RHDEBCF – Double fitted fleecy electric blanket- 220-240V- 50Hz 60W X2

RHQEBCF – Queen fitted fleecy electric blanket - 220-240V- 50Hz 60W X2


RHKEBCF - King fitted fleecy electric blanket- 220-240V - 50Hz 60W X2

FITMENT

Your "fitted" electric blanket has an elastic skirt sewn in to keep it flat and taut on the mattress and makes it easier to fit and remove from the bed.

- Place the electric blanket on your bed with the controller at the pillow end.

Ensure it does not overhang the bed edge and is not under the area intended for the pillow(s). Smooth out the folds and wrinkles then secure the elastic "fitted" skirt over each of the four corners of the bed.



OPERATION - BEFORE USE

- Once the electric blanket has been installed correctly in position and the bedding completed, connect the controller supply plug to a suitable power outlet.
- Ensure the controller is set to OFF.
- Switch the power ON. Select the desired heat setting on the controller.
- The indicator lamp indicates when the blanket is ON.
- For first time use it is recommended that the electric blanket be set to HIGH for two hours before sleeping on the bed.
- This will assist in drying any moisture out of the mattress.
- Ignore any initial odour which may occur with first time use.

EVERYDAY USE

With normal use your electric blanket will require 20 minutes of pre-heating on the maximum setting before bedtime. We recommend that you turn the blanket off when sleeping.

1. For normal use select the desired heat on the controller.

WARNING: Do NOT sleep with the controller set to HIGH. Use the HIGH setting only to pre-heat the bed, then reduce the heat setting to MEDIUM or LOW. Set to OFF when the heat is no longer required. Remember to switch the blanket off at the end of use.

2. It is recommended that this blanket is used with a residual current safety device (safety switch) with a rated residual operating current not exceeding 30 mA.
3. This blanket is not to be used by young children unless the controls have been pre-set by a parent or guardian or unless the child has been adequately instructed on how to operate the controls safely.

CONTROLS

The braille markings on the control switch allow easy adjustment of the temperature in the dark.

Each controller has the following settings:

0. Off
1. Low heat
2. Medium heat (all night use)
3. High or pre-heat. Use this setting to pre-heat the bed one or two hours before use only. **WARNING:** Do NOT sleep with the control set to this setting.

POWER SUPPLY

- This electric blanket must be connected to a suitable 230/240V-50Hz power supply.
- If using an extension cord, ensure the extension is of suitable 10 amp power rating.
- Fully unwind the power supply cord when in use as a coiled cord may overheat.
- Always unplug from the mains supply when not in use.
- The lead between the blanket and controller may get warm during operation - this is normal and safe.
- If the supply cord or controller is damaged, it must be replaced by the manufacturer or its service agent or similarly qualified person in order to avoid a hazard.

STORING YOUR BLANKET

If you wish to remove your blanket from the bed when not in use, roll or fold the blanket LOOSELY and store in a blanket bag or the polybag it was supplied in.

Avoid pressing sharp creases into the blanket when storing as this could damage the blanket's heating wires.

CLEANING

WARNING: Do **NOT** dry clean this electric blanket. This may damage the heating element or controller.

- Do **NOT** iron this blanket.
- Do **NOT** machine wash or machine dry. The heating wires are fully water-proofed to allow for washing.
- When not in use and before cleaning, always disconnect the blanket from the mains supply.
- Roll up the securing tie tapes before cleaning. This will prevent them becoming tangled or damaged.

HAND WASHING

- Immerse the blanket **ONLY** in luke warm neutral detergent or mild soapy water solution.
- Do **NOT** allow controller or the section of blanket where the cord enters to be immersed in any liquid.
- Soak for five minutes, remove and gently squeeze the liquid from the blanket as much as possible without wringing the blanket.
- Rinse only in clean water and remember never to immerse the controller in water.
- Drape the blanket over a clothes line to dry.
- Allow the blanket to dry naturally and ensure liquid never enters the controller by securing it away from dripping water.
- Do **NOT** use pegs to secure. Never use any appliance such as a heater or hair dryer to hasten the drying process
- Do **NOT** use pegs to secure. Never use any appliance such as a heater or hair dryer to hasten the drying process.

SPOT CLEANING

Unplug and remove the control unit. Wet sponge the affected area using a mild soap and luke warm water. Ensure the water temperature is less than 30 degrees Celsius. Gently sponge the affected area with new clean water and use a white coloured towel to absorb excess moisture.






MAINTENANCE

Always check that the blanket is in good working condition before use. Check the controller, power supply cord and plug frequently for cuts and damage.

Do **NOT** attempt to service this blanket. There are NO user serviceable parts. If it is faulty in anyway, return it to the retailer immediately.

This electric blanket should be checked annually by a suitably qualified person to ensure its safety and suitability for use.

When not in use, store your blanket and instruction manual in a safe and dry place.

	Hand wash only
	Do not bleach
	Line Dry/hang to dry – hang damp from line or bar and allow to dry
	Do not iron or press with heat
	Do not dry clean

**PLEASE AFFIX YOUR PROOF OF PURCHASE/RECEIPT HERE
IN THE EVENT OF A CLAIM UNDER WARRANTY THIS RECEIPT MUST BE PRODUCED.**

2 YEAR WARRANTY

*1 year retail | 1 year extended
warranty upon registration*
visit www.russellhobbs.co.za*

W A R R A N T Y AND EXTENDED WARRANTY

1. Home of Living Brands (Pty) Limited ("Home of Living Brands") warrants to the original purchaser of this product ("the customer") that this product will be free of defects in quality and workmanship which under normal personal, family or household use and purpose may manifest within a period of 1 (one) year from the date of purchase ("warranty period").
2. Home of Living Brands shall extend the warranty period for a further period of 1(one) year ("extended warranty period"), on condition that the purchaser registers the product on the website, within 12 months from the date of purchase of the product. The website address for registration is as follows: <http://russellhobbs.co.za/info-pages/warranty-info.aspx>. The extended warranty period only applies to products purchased on or after 1 October 2017.
3. Where the customer has purchased a product and it breaks, is defective or does not work properly for the intended purpose, the customer must notify the supplier from whom the customer bought the product ("the supplier") thereof within the warranty period or if applicable, the extended warranty period. Any claim in terms of this warranty must be supported by a proof of purchase. If proof of purchase is not available, then repair, and/or service charges may be payable by the customer to the supplier.
4. The faulty product must be taken to the supplier's service centre to exercise the warranty.
5. The supplier will refund, repair or exchange the product in terms of this warranty subject to legislative requirements. This warranty shall be valid only where (a) the customer is not the cause of the product breaking, and (b) the product has been used for the intended purpose stipulated in the product manual. The warranty does not include and will not be construed to cover products damaged as a result of disaster, misuse, tamper, abuse or any unauthorised modification or repair of the product.
6. This warranty will extend only to the product provided at the date of the purchase and not to any expendables attached or installed by the customer. In this regard any accessories supplied with the product by the supplier, may be excluded in this warranty or extended warranty (see Exclusions to Warranty and Extended Warranty document).
7. If the customer requests that the supplier repairs the product and the product breaks or fails to work properly within 3 (three) months of the repair and not as a result of misuse, tampering or modification by or on behalf of the customer, then the supplier may replace the product or pay a refund to the customer, subject to the supplier's discretion.
8. The customer may be responsible for certain costs where products returned are not in the original packaging, or if the packaging is damaged. This will be deducted from any refund paid to the customer.

HOME OF LIVING BRANDS (PTY) LTD (JOHANNESBURG)

JOHANNESBURG
NATIONAL NUMBER

TEL NO. (011) 490-9600
TEL NO. (087) 245-

0029

www.homeoflivingbrands.com
www.russellhobbs.co.za

www.facebook.com/RussellHobbsSA

EXCLUSIONS TO WARRANTY AND EXTENDED WARRANTY

1. Any accessories supplied with the product, including but not limited to, bowls, jugs, mills or carafes made either of glass or plastic and supplied with this appliance (hereinafter referred to as "the accessory or accessories"), is warranted to be free from material and workmanship defects for the duration of the appliance warranty.
2. The accessories should give trouble free service when used in accordance with the directions described in the instruction manual. However, the accessories will be damaged if subjected to impact, and this damage is not covered by the warranty. Such impact damage can occur either from the outside (if for example it is dropped or knocked against a hard surface), or from within (if for example foreign objects are placed within the accessories and the power is switched on).
3. Should you need to replace an accessory during the warranty period; a claim for a free replacement will only be considered if the item (including all shards and broken parts) is returned to the nearest HOLB service centre for examination.
4. The remains of the accessory will be carefully examined by the relevant professionals and if it is determined (at the sole discretion of HOLB) that the damage was caused by impact, then the claim will be refused and will not be covered by the warranty or any extended warranty.

Any replacement part provided in terms of clause 4 above will become a chargeable item payable by the customer