



## Mobile Bluetooth Speaker - CT3011

### User Manual



Tel: (RSA) 010 140 4900 / Email: [sales@parrot.co.za](mailto:sales@parrot.co.za)  
[www.parrot.co.za](http://www.parrot.co.za)

## Includes:


- 1 x Charging cable
- 1 x 3.5mm dual audio cable

## Wireless function:

1. Turn ON the speaker by holding the power button for 3 seconds.  
A blue LED light should appear.
2. Wireless function: Activate your Bluetooth device , search for the wireless speaker name CT3011 and then connect. Once successfully paired the blue LED indicator will stop flashing.
3. Hands-free phone calls: Once your mobile phone is connected to the speaker via Bluetooth, you can answer incoming calls by short pressing the PLAY button and hang up the call by double pressing the PLAY button.

**Note: If the Bluetooth connection is not successful and active for 10 minutes, the Bluetooth function will automatically switch off until activated again.**

## Button function description:



- ① POWER Button
- ② PLAY / PAUSE / HANDS-FREE CALLS - short press  
MODE - long press to switch between TF card / AUX / Wireless modes
- ③ VOLUME DOWN / PREVIOUS - short press to lower volume or  
long press to play previous song
- ④ VOLUME UP / NEXT - short press to increase volume or  
long press to play next song.

**Note: When the battery is at 10% power or less the speaker will prompt a sound to put the speaker on charge. The speaker will automatically switch off when the battery is at 3% power or less.**

## **Indicator Status:**

Wireless not connected: Blue LED light flashes fast

Wireless connected: Blue LED light stops flashing

Playing music: Blue LED light flashes slowly

Charging: Red LED light flashes. Once completely charged the red LED stops flashing.

## **Power Bank function:**

Connect the charging cable to the speaker and a USB charger.  
The Red LED light will flash while charging.

## **TF card function:**

During booting state, insert the TF card and hear for the sound which indicates the speaker has switched to TF card mode. Audio will play automatically after 2 seconds. Files on the TF card must be in MP3 or WAV format.

## **External audio AUX input function:**

The 3.5mm dual audio cable is suitable for use with PC, iPOD, Mobile Phone, MP3 and MP4 devices

## **Usage and Storage environment conditions:**

Usage:

Use environment Temperature: 0 ~ 40°C,

Humidity: 0% ~ 85%RH

Storage:

Storage environment temperature -30 ~ 60°C,

Humidity: 0% ~ 90%RH

# Technical specifications

## CT3011 Technical features:

<b>Category</b>	Mobile Bluetooth Speaker
<b>Output maximum power</b>	4.1 + EDR
<b>Capacity of lithium battery</b>	4500mAh
<b>Speaker specification</b>	Diameter 45mm, 4Ω 8W x 2, double horn
<b>Noise ratio</b>	≥80DB
<b>Distortion</b>	THD = 1%
<b>Lithium battery operating time</b>	6~12 hours
<b>Charging volatge / current</b>	5V 0.5A-1.5A
<b>Support TF card music format</b>	MP3 WAV
<b>Transmission distance</b>	10M
<b>Bluetooth</b>	4.1

Refer to our website [www.parrot.co.za](http://www.parrot.co.za) for warranty information